OPERATING INSTRUCTIONS FOR NDCC SCOREBOARD

Set up and Run a New Game

1. Press ON/OFF switch on right side of console. Read message displayed on console

- 2. Message Start where turned off press NO
- 3. Messagè Use a bookmark press NO
- 4. Message Enter model number enter 871
- 5. Message Penalty Time Out press NO

Set time and period number

- 6. Press SET
- 7. Press TIME
- 8. Enter duration of period eg **030000** for warmup, **150000** for 15 minute period press **YES**
- 9. Enter period number eg 0 for warmup, 1 for first period

Starting Another Period

- 1. Press SET
- 2. Press TIME
- 3. Enter duration of period eg **15000** for 15 minute period
- 4. Enter period number eg 2 for second period

Start and stop the clock

- 1. To run the clock use attached control button on top will start/stop the clock
- 2. Bottom button will sound horn to alert the refs of a problem

Clock should now be set for start of period

Set-up a Goal

- 1. Press **Home Score** or **Guest Score** button on right
- 2. Enter 1
- 3. Press YES to confirm

Cancelling/Correcting a Goal

- 1. Press SET
- 2. Press Home Score or Guest Score
- 3. Enter correct score with keypad
- 4. Press YES to confirm

Score will be incremented by 1.

Set-up a Penalty

- 1. Press SET
- 2. Press Home Penalty or Guest Penalty
- 3. Enter penalty minutes eg 0200 or 0400
- 4. Press YES to confirm
- 5. Enter 2 digit player number eg 07
- 6. Press YES to confirm

Cancelling a Penalty

- 1. Press Home Penalty or Guest Penalty until correct penalty is displayed on monitor
- 2. Press Penalty Clear
- 3. Press YES to confirm

NOTES:

1. If a team has 2 penalties already on the clock and a 3rd, etc., non-coincidental penalty assessed follow instructions above to record a penalty. The third penalty will begin when one of the existing penalties expires.

